



NB. for detailed information please refer to OEM wiring schematic

## Colour Coded Wiring Loom Installation Plan

Lucas Part Number 54955256/57095  
 Triumph T120/TR6 1969-70 UK & USA Specification

Trust **Lucas**